



RAMUC[®]

Clean & Prep Solution

Cleans and Prepares Surfaces for proper adhesion prior to painting.



Clean & Prep Solution is used to clean and degrease while simultaneously dissolving mineral deposits, and increasing porosity for good adhesion on surfaces prior to painting. Can be used on painted surfaces, bare plaster, concrete or fiberglass. VOC compliant, odor and fume free, water-rinse neutralize and it is biodegradable. Safe to use near plants or grass. Excellent for filter element cleaning.

www.ramucpoolpaint.com

Cleans, Degreases & Prepares Pool Surfaces for Proper Adhesion Prior to Painting

- Odor Free
- Bio Degradable
- VOC Compliant in the US and Canada
- Replaces TSP/Acid Etch/TSP
- Safe and Easy to use
- Cleans Filter Elements



NOTES

Proper surface preparation is paramount before painting your pool or aquatic installation. It is essential to remove oil or residue otherwise the coating will not adhere effectively.

Clean & Prep turns the traditional 3-Step Process (TSP, Muriatic Acid, TSP) into 1-Step

Clean & Prep will perform best on a surface that has been properly prepared for cleaning. After all repairs have been completed, power wash loose material off to a tight surface.

Use **Clean & Prep** when temperatures are at 50° overnight and no more than 85° ambient during daytime hours.

DIRECTIONS

- Mix **Clean & Prep** as directed on label and according to surface type.
- Dampen surface with water.
- Apply **Clean & Prep** with a garden sprayer for even application
- Do not let the solution “set” on surface, other than to make sure it is etching. Begin scrubbing immediately after applying and you will see the solution begin to foam.
- Scrub thoroughly until foaming stops. Be sure the heavily soiled areas (such as waterline, steps or regular footpaths on concrete decks) are scrubbed well.
- Triple rinse the surface with a strong stream of clean water while scrubbing to ensure complete removal of all material. Do not let solution dry on the surface. Rinse all at once and until foam is completely gone. Paint will not adhere to residual **Clean & Prep** Solution so rinsing thoroughly is an important step. **DO NOT POWERWASH RESIDUAL CLEAN & PREP.**
- Clean all application tools with water immediately after use.

It is recommended to wait 5 days after cleaning for the pool to be thoroughly dry before painting. A light rain is generally not an issue during the 5 day waiting period unless there is a concern about “Acid Rain”.

(**NOTE) *Follow all instructions and warnings on product label.*